



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
VIDEO	/ SOURCE
GOTO	-/--
TIMESHIFT	
SUBTITLE	
SETUP	
TEXT	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
REPEAT	BACK
INFO	INFO
GUIDE	EPG
FAV	FAV

ORIGINAL	SUPERIOR
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
MOVIE	SHIFT+1
MUSIC	SHIFT+2
PHOTO	SHIFT+3
FILES	SHIFT+4
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
PAUSE	SHIFT+
STOP	SHIFT+
REW	SHIFT+GREEN
REC	SHIFT+RED
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

