



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DEVICE	 / SOURCE
GO TO	-/--
FULL SCREEN	
ZOOM	
COPY	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
INFO	INFO
DIGEST	FAV
PAUSE	
STOP	 / SMART

ORIGINAL	SUPERIOR
REW	GREEN
PLAY	YELLOW
FWD	BLUE
AUDIO	SHIFT+MUTE
SETUP	SHIFT+MENU
FILE	SHIFT+1
MOVIE	SHIFT+2
MUSIC	SHIFT+3
PHOTO	SHIFT+4
VIDEO OUT	SHIFT+ 
ASPECT	SHIFT+ 
ROTATE	SHIFT+ 
SELECT / BGM	SHIFT+OK
REPEAT	SHIFT+BACK
BACKLIGHT	SHIFT+INFO

