



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
/ MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
LIST	-/--
16 : 9	
SNAPSHOT	
/ TTX	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
L/R	TV/DTV
INFO	INFO
/	EPG
HOLD	/ SMART

ORIGINAL	SUPERIOR
RED	RED
GREEN / SUBTITLE	GREEN
YELLOW / FAV	YELLOW
BLUE / EPG	BLUE
3D/F1	SHIFT+3
REVEAL	SHIFT+
ZOOM / TS	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
	SHIFT+BACK
RADIO	SHIFT+TV/DTV
INDEX	SHIFT+INFO
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

