



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	/ SOURCE
CH./LIST / SET	-/--
DISPLAY	
PICTURE	
LIST / D-MENU	
TV/TXT / PRO	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SLEEP	SLEEP
INDEX	INFO
EPG / LAN	EPG

ORIGINAL	SUPERIOR
FAV	FAV
HOLD	/ SMART VIDEO
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE / SCREEN	BLUE
SOUND	SHIFT+MUTE
CANCEL / SLOW	SHIFT+EXIT
NICAM / A2	SHIFT+1
SIZE	SHIFT+
SUBTITLE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
SUBPAGE	SHIFT+DOWN
REP. / REVEAL	SHIFT+BACK
PAUSE	SHIFT+
STOP	SHIFT+
RECORD / EJECT	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

