



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	 / AV
-/--	-/--
MODE	
DTV MENU	
TTX	
VOL+	VOL+
VOL-	VOL-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
TV / RADIO	TV/DTV
INFO	INFO
GUIDE	EPG
RED / FAV	RED
GREEN / AUDIO	GREEN
YELLOW / SUBTITLE	YELLOW

[illegible]