



ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
-/--	-/--
/ HOME	
SIZE	
S.MODE	
TEXT/CC	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
T.SHIFT	SLEEP
P.MODE	TV/DTV
LIST	INFO

ORIGINAL	SUPERIOR
EPG	EPG
FAV	FAV
NETFLIX	/ NET TV
YOUTUBE	/ SMART TUBE
PRIME VIDEO	/ SMART VIDEO
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE / ..	BLUE
MTS/II	SHIFT+MUTE
SET	SHIFT+MENU
REVEAL	SHIFT+
HOLD	SHIFT+
ASPECT	SHIFT+
SUB - T	SHIFT+
SKIP NEXT/PREV	SHIFT+ P+/-
INDEX	SHIFT+INFO
SUB.PG	SHIFT+EPG
AUTO	SHIFT+FAV
FREEZE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY/PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

