



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
[Icon] / [Icon] / MENU	MENU
[Icon] / [Icon] / EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
[Icon] / [Icon] / SOURCE	[Icon] / SOURCE
[Icon] / -/--	-/--
[Icon] / TV	[Icon]
[Icon]	[Icon]
[Icon] / [Icon] / TTX/MIX	[Icon]
VOL+	VOL+
VOL-	VOL -
[Icon] / P+	P+
[Icon] / P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
[Icon] / ENTER	OK
[Icon] / PRE - CH	BACK
[Icon] / SLEEP	SLEEP
[Icon] / INFO	INFO
RED/TURBO	RED
GREEN/S. MENU	GREEN

ORIGINAL	SUPERIOR
YELLOW/S.MODE	YELLOW
BLUE/P.MODE	BLUE
[Icon] / DUAL I - II	SHIFT+MUTE

