



ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
R. LIST	-/--
DISPLAY	
SIZE	
MIX	
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SLEEP	SLEEP
TV / RADIO	TV/DTV
SUBPAGE	INFO

ORIGINAL	SUPERIOR
EPG	EPG
FAV	FAV
HOLD	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO / I/II	SHIFT+MUTE
MEDIA	SHIFT+6
REVEAL	SHIFT+
S. MODE	SHIFT+
P. MODE	SHIFT+
SUBTITLE	SHIFT+
SKIP MEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
T. SHIFT	SHIFT+SLEEP
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

