



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	/ SOURCE
LIST	-/--
PICTURE	
VOL+	VOL+
VOL -	VOL-
PROG+	P+
PROG -	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
SLEEP	SLEEP
TV / DTV	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
GUIDE	EPG
FAVORITE	FAV
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
TV AUDIO	SHIFT+MUTE
DTV MENU	SHIFT+MENU
SOUND	SHIFT+1
	SHIFT+2
	SHIFT+3
	SHIFT+
WIDE	SHIFT+
	SHIFT+
SUBTITLE	SHIFT+
TV / RADIO	SHIFT+TV/DTV
	SHIFT+INFO

