



DVD/USB/CARD	 / SOURCE
10+	-/--
OSD	
ZOOM	
ANGLE	
SUBTITLE	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
REPEAT	BACK
TITLE	INFO
PROGRAM	EPG
SEARCH	FAV

[illegible]