



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	 / SOURCE
TIMESHIFT	-/--
EDIT	
NAVIGATE	
COPY	
BROWSER	
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
TIMER	SLEEP
HDD/DVD	TV/DTV
INFO	INFO
GUIDE	EPG
TOOLS	FAV
EJECT	 / NET TV
PAUSE	
STOP	 / SMART

[illegible]