



ORIGINAL	SUPERIOR
	POWER
	MUTE
	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
	 / SOURCE
LIST	-/--
	
	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
T	TV/DTV
NETFLIX	 / NET TV
YOUTUBE	 / SMART TUBE
MEDIA	SHIFT+6
 / 	SHIFT+ 
	SHIFT+ 

[illegible]