



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
BASS	1
TREBLE	2
TIMER SET	3
FM/AM	 / SOURCE
FM MODE	-/--
FUNCTION	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	CH+
SKIP PREV	CH -
OK	OK
SCROLL UP	UP
SCROLL DOWN	DOWN
PRESET NEXT	RIGHT
PRESET PREV	LEFT
MEMORY	EPG
SHUFFLE	FAV
PLAY	YELLOW
PAUSE	
STOP	 / SMART
TIMER	INFO

[illegible]