



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MUTING	MUTE
MENU	MENU
INPUT NEXT	 / SOURCE
INPUT TUNER	-/--
VOL+	VOL+
VOL -	VOL -
PRESET/SCROLL UP	UP
PRESET/SCROLL D.	DOWN
SKIP PREV./TUNE D.	LEFT
SKIP NEXT/TUNE UP	RIGHT
OK	OK
SLEEP	SLEEP
BASS	INFO
TREBLE	EPG
SHUFFLE	FAV
PAUSE	
STOP	 / SMART
REW	GREEN
PLAY	YELLOW
FWD	BLUE
TIMER	SHIFT+POWER

[illegible]