



| ORIGINAL        | SUPERIOR                                                                          |
|-----------------|-----------------------------------------------------------------------------------|
| POWER           | POWER                                                                             |
| MUTE            | MUTE                                                                              |
| MENU            | MENU                                                                              |
| 1/2/3/4/5       | 1/2/3/4/5                                                                         |
| 6/7/8/9/0       | 6/7/8/9/0                                                                         |
| +10             | -/--                                                                              |
| MULTIREAR       |  |
| EFFECT          |  |
| SUBWOOFER       |  |
| LEVEL           |  |
| VOL+            | VOL+                                                                              |
| VOL -           | VOL -                                                                             |
| UP              | UP                                                                                |
| DOWN            | DOWN                                                                              |
| LEFT            | LEFT                                                                              |
| RIGHT           | RIGHT                                                                             |
| OK              | OK                                                                                |
| DOLBY II        | SLEEP                                                                             |
| INPUT TV        | TV/DTV                                                                            |
| STEREO          | INFO                                                                              |
| DTS             | EPG                                                                               |
| TEST            | FAV                                                                               |
| MODE            | RED                                                                               |
| SURROUND TOGGLE | GREEN                                                                             |
| SURROUND ON     | YELLOW                                                                            |

| ORIGINAL       | SUPERIOR                                                                                   |
|----------------|--------------------------------------------------------------------------------------------|
| ENHANCED SURR. | BLUE                                                                                       |
| CD             | SHIFT+1                                                                                    |
| DVD            | SHIFT+2                                                                                    |
| VCR            | SHIFT+3                                                                                    |
| TAPE           | SHIFT+4                                                                                    |
| AUX            | SHIFT+5                                                                                    |
| PHONO          | SHIFT+ 6                                                                                   |
| VDP            | SHIFT+7                                                                                    |
| VCR 2          | SHIFT+8                                                                                    |
| TAPE 2         | SHIFT+9                                                                                    |
| 6 CH           | SHIFT+0                                                                                    |
| DIGITAL        | SHIFT+  |
| SFC            | SHIFT+  |
| DIMMER         | SHIFT+  |
| DIRECT TUNE    | SHIFT+  |
| VOL. REAR+     | SHIFT+ VOL+                                                                                |
| VOL. REAR -    | SHIFT+ VOL -                                                                               |
| VOL. CENTER+   | SHIFT+ P+                                                                                  |
| VOL. CENTER -  | SHIFT+ P -                                                                                 |
| EFFECT+        | SHIFT+UP                                                                                   |
| EFFECT -       | SHIFT+DOWN                                                                                 |
| DEFAULT PREV   | SHIFT+LEFT                                                                                 |
| DEFAULT NEXT   | SHIFT+RIGHT                                                                                |
| BANDA          | SHIFT+FAV                                                                                  |
|                |                                                                                            |

