




ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
	 / SOURCE
INST.	
	
V+	VOL+
V -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
PP	OK
?	BACK
	TV/DTV
 / I - II	INFO
	EPG
RED / 	RED
GREEN / SOUND	GREEN
YELLOW / 	YELLOW
BLUE / 	BLUE

[illegible]