



ORIGINAL	SUPERIOR
	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SAT	/ SOURCE
/ FILELIST	-/--
V – FORMAT	
WIDE	
A – Z	
TEXT	
VOL+	VOL+
VOL -	VOL -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
/ RECALL	BACK
/ SLEEP	SLEEP
TV / SAT	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV

ORIGINAL	SUPERIOR
FREEZE	
MEDIA	/ SMART
RED / BOOKMARK	RED
GREEN / MOSAIC	GREEN
YELLOW / COLOR	YELLOW
BLUE / POS	BLUE
AUDIO	SHIFT+MUTE
USB	SHIFT+
PIP	SHIFT+
PIP LIST	SHIFT+
PIP SWAP	SHIFT+
/ SUBTITLE	SHIFT+
ADVANCE / LAN / -> 	SHIFT+RIGHT
SLOW	SHIFT+SLEEP
TV/RADIO	SHIFT+TV/DTV
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

