



ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU / PBC	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
MODE	 / SOURCE
ANGLE	-/--
DISPLAY	
GOTO	
SETUP	
SUBTITLE	
SKIP NEXT	P+
SKIP PREV	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
REPEAT	BACK
STEP	SLEEP
RAN. / PROG.	TV/DTV
TITLE/RETURN	INFO
SLOW	EPG
AUDIO	FAV
OPEN/CLOSE	 / NET TV

[illegible]