



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SAT	 / SOURCE
NTSC/PAL	-/--
TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
LAST	BACK
TV/SAT	TV/DTV
i	INFO
GUIDE	EPG
FAV	FAV
PAUSE	
RED	RED

[illegible]