



ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU	MENU
EXIT / SLOW	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DVD / DVB	/ SOURCE
P/N	-/--
DISPLAY / INFO	
ANGLE	
TXT / SEARCH	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
TV/RADIO / Q-PLAY	TV/DTV
GAME	INFO
EPG / RANDOM	EPG
FAV / A-B	FAV

ORIGINAL	SUPERIOR
RED	RED
GREEN	GREEN
YELLOW / LIST	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
PBC / DIGEST	SHIFT+ -/--
VIDEO	SHIFT+
ZOOM	SHIFT+
SETUP	SHIFT+
SUBTITLE	SHIFT+
PAGE UP	SHIFT+UP
PAGE DOWN	SHIFT+DOWN
NEXT	SHIFT+ P+
PREV	SHIFT+ P -
MEDIA	SHIFT+SLEEP
TITLE	SHIFT+INFO
OPEN/CLOSE	SHIFT+
PAUSE	SHIFT+
STOP / SLEEP	SHIFT+
REC / REPEAT	SHIFT+RED
REW	SHIFT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FF	SHIFT+BLUE

