



ORIGINAL	SUPERIOR
POWER	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
CH LIST	-/--
HOME	
PICTURE	
MIX	
TEXT/C.C.	
VOL +/-	VOL +/-
CH +/-	P +/-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
BACK/RETURN	BACK
SLEEP	SLEEP
TV/RADIO	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV

ORIGINAL	SUPERIOR
BROWSER	/ NET TV
YOUTUBE	/ SMART TUBE
HOLD/FREEZE	/ SMART VIDEO
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
MTS / I/II	SHIFT+MUTE
CACNEL	SHIFT+EXIT
PVR LIST	SHIFT+ -/--
REVEAL	SHIFT+
ZOOM	SHIFT+
SIZE	SHIFT+
SUBTITLE	SHIFT+
SKIP PREV/NEXT	SHIFT+ P +/-
QUICK	SHIFT+BACK
AD	SHIFT+TV/DTV
INDEX	SHIFT+INFO
SUBPAGE	SHIFT+EPG
SOUND	SHIFT+FAV
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY/PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

