



ORIGINAL	SUPERIOR
	POWER
	MUTE
MODE	MENU
LOUDNESS	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
10+	-/--
DISPLAY	
INTRO	
P – EQ	
CLOCK	
VOL+	VOL+
VOL -	VOL -
SKIP NEXT	P+
SKIP PREV	P -
ALB+	UP
ALB -	DOWN
A – B	BACK
SLEEP/TIMER	SLEEP
RANDOM	TV/DTV
DIM	INFO
PROG	EPG
S – BASS	FAV
EJECT	 / NET TV
STOP	 / SMART VIDEO

[illegible]