



| ORIGINAL   | SUPERIOR  |
|------------|-----------|
| POWER      | POWER     |
|            | MUTE      |
| MENU       | MENU      |
| EXIT       | EXIT      |
| 1/2/3/4/5  | 1/2/3/4/5 |
| 6/7/8/9/0  | 6/7/8/9/0 |
| SOURCE     | / SOURCE  |
| T – SHIFT  | -/--      |
| REVEAL     |           |
| SIZE       |           |
| INDEX      |           |
| TXT/REPEAT |           |
| VOL+       | VOL+      |
| VOL -      | VOL -     |
| CH+        | P+        |
| CH -       | P -       |
| UP         | UP        |
| DOWN       | DOWN      |
| LEFT       | LEFT      |
| RIGHT      | RIGHT     |
| OK         | OK        |
|            | BACK      |
| SLEEP      | SLEEP     |
| DTV/RADIO  | TV/DTV    |
| INFO       | INFO      |

| ORIGINAL         | SUPERIOR     |
|------------------|--------------|
| EPG              | EPG          |
| ASPECT           | / NET TV     |
| HOLD/FREEZE      | / SMART      |
| RED              | RED          |
| GREEN            | GREEN        |
| YELLOW           | YELLOW       |
| BLUE             | BLUE         |
| NICAM            | SHIFT+MUTE   |
| P.MODE           | SHIFT+       |
| S.MODE           | SHIFT+       |
| SUBPAGE/SUBTITLE | SHIFT+       |
| SKIP NEXT        | SHIFT+ P+    |
| SKIP PREV        | SHIFT+ P -   |
| STOP             | SHIFT+       |
| REC              | SIFT+RED     |
| REW              | SIFT+GREEN   |
| PLAY/PAUSE       | SHIFT+YELLOW |
| FWD              | SHIFT+BLUE   |
|                  |              |
|                  |              |
|                  |              |
|                  |              |
|                  |              |
|                  |              |
|                  |              |
|                  |              |

