



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
MENU / EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
MODE	 / SOURCE
-/--	-/--
PICTURE	
SIZE	
16 : 9	
TXT / MIX	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK / ENTER	OK
	BACK
SLEEP	SLEEP
TV / RADIO	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
EPG	EPG
FAV	FAV
HOLD	 / SMART
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
TIMER	SHIFT+POWER
AUDIO	SHIFT+MUTE
CALL	SHIFT+MENU
CANCEL	SHIFT+EXIT
PIP	SHIFT+1
LIST	SHIFT+ -/--
REVEAL	SHIFT+ 
S – SWAP	SHIFT+ 
P – SWAP	SHIFT+ 
SUBTITLE	SHIFT+ 
POSITION	SHIFT+OK
INDEX	SHIFT+INFO
SUBPAGE	SHIFT+EPG
NICAM / A2	SHIFT+FAV

