



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV / AV	AV
-/--	-/--
DISPLAY	
PIC. SIZE	
MIX	
TEXT	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
SLEEP	SLEEP
INFO	INFO
EPG	EPG

ORIGINAL	SUPERIOR
FAV	FAV
AUTO	
STILL	
HOLD	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
CYAN	BLUE
AUDIO	SHIFT+MUTE
SYSTEM	SHIFT+MENU
CANCEL	SHIFT+EXIT
P. MODE	SHIFT+1
S. MODE	SHIFT+2
NICAM / A2	SHIFT+3
DVB SOURCE	SHIFT+AV
REVEAL	SHIFT+ 
SIZE	SHIFT+ 
SUBTITLE	SHIFT+ 
FAV-	SHIFT+LEFT
FAV+	SHIFT+RIGHT
SUB PAGE	SHIFT+DOWN
INDEX	SHIFT+INFO

