



ORIGINAL	SUPERIOR
	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	/ SOURCE
-/--	-/--
DISPLAY / INFO	
SIZE	
LANGUAGE	
TV / TXT	
VOL+ / RIGHT	VOL+
VOL - / LEFT	VOL -
CH+ / UP	P+
CH - / DOWN	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SLEEP	SLEEP
NICAM / A2	TV/DTV
INDEX	INFO

ORIGINAL	SUPERIOR
EPG	EPG
FAV	FAV
PICTURE	/ NET TV
HOLD	/ SMART
RED / TV/RADIO	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
SOUND	SHIFT+MUTE
REVEAL	SHIFT+
ZOOM	SHIFT+
DVB	SHIFT+
TEXT	SHIFT+
FAV -	SHIFT+LEFT
FAV+	SHIFT+RIGHT
SUBPAGE	SHIFT+DOWN
CANCEL	SHIFT+BACK
SUBTITLE	SHIFT+FAV

