



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9	6/7/8/9
0 / -/--	0
AV	 / SOURCE
TEXT / PURPLE	
VOL +	VOL +
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT / ZOOM -	LEFT
RIGHT / ZOOM +	RIGHT
OK	OK
BACK	BACK
RED / PRESETS	RED
GREEN / ZZZ / LIST	GREEN
YELLOW / INFO	YELLOW
BLUE / GUIDE	BLUE

[illegible]