



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ AV
-/--	-/--
DISPLAY	
SIZE	
MIX	
TEXT	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SLEEP	SLEEP
TV / RADIO	TV/DTV
INDEX	INFO

ORIGINAL	SUPERIOR
CLOCK	EPG
FAV / LIST	FAV
ASPECT	
FREEZE	
HOLD	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
CYAN	BLUE
NICAM	SHIFT+MUTE
CANCEL	SHIFT+EXIT
P. MODE	SHIFT+1
S. MODE	SHIFT+2
LIST	SHIFT+ -/--
REVEAL	SHIFT+
SUBPAGE	SHIFT+DOWN

