



| ORIGINAL      | SUPERIOR  |
|---------------|-----------|
| STANDBY       | POWER     |
| MUTE          | MUTE      |
| MENU          | MENU      |
| EXIT          | EXIT      |
| 1/2/3/4/5     | 1/2/3/4/5 |
| 6/7/8/9/0     | 6/7/8/9/0 |
| SOURCE        | / AV      |
| 10+ /         | -/--      |
| DISPLAY       |           |
| VOL+          | VOL+      |
| VOL-          | VOL-      |
| CH+           | P+        |
| CH-           | P-        |
| UP            | UP        |
| DOWN          | DOWN      |
| LEFT          | LEFT      |
| RIGHT         | RIGHT     |
| OK            | OK        |
| SLEEP         | SLEEP     |
| TV / RADIO    | TV/DTV    |
| TITLE         | INFO      |
| FAV / PROGRAM | FAV       |
| ASPECT / SIZE |           |
| RED / GO TO   | RED       |
| GREEN / A-B   | GREEN     |

| ORIGINAL           | SUPERIOR     |
|--------------------|--------------|
| YELLOW / ANGLE     | YELLOW       |
| BLUE / REPEAT      | BLUE         |
| I/II / AUDIO       | SHIFT+MUTE   |
| D. MENU            | SHIFT+MENU   |
| P. MODE            | SHIFT+1      |
| S. MODE            | SHIFT+2      |
| ZOOM               | SHIFT+       |
| D. SETUP           | SHIFT+       |
| SUBTITLE           | SHIFT+       |
| SKIP PREV. / INDEX | SHIFT+ P-    |
| SKIP NEXT / MIX    | SHIFT+ P+    |
| TIMESHIFT          | SHIFT+SLEEP  |
| EJECT              | SHIFT+       |
| STOP / REVEAL      | SHIFT+       |
| REC                | SHIFT+RED    |
| REW / TEXT         | SHIFT+GREEN  |
| PLAY/PAUSE / HOLD  | SHIFT+YELLOW |
| FWD / SUBPAGE      | SHIFT+BLUE   |
|                    |              |
|                    |              |
|                    |              |
|                    |              |
|                    |              |
|                    |              |
|                    |              |
|                    |              |

