



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
SEARCH	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
FUNC.	/ AV
RESUME	-/--
DISPLAY	
ZOOM	
SETUP	
SUBTITLE	
VOLUME+	VOL+
VOLUME-	VOL-
SKIP NEXT	P+
SKIP PREV.	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
REPEAT	BACK
SLOW	SLEEP
PAL / NTSC	TV/DTV
TITLE	INFO

ORIGINAL	SUPERIOR
MEMO	EPG
LANGUAGE	FAV
EJECT	
STOP	
F. R.	GREEN
PLAY / PAUSE	YELLOW
F. F.	BLUE
EQ.	SHIFT+
A - B	SHIFT+
TRE.	SHIFT+
BASS	SHIFT+
RECALL	SHIFT+BACK
BAND	SHIFT+SLEEP
CH.	SHIFT+TV/DTV
ANGLE	SHIFT+INFO
PBC	SHIFT+EPG

