



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
MENU OFF	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV	 / AV
	-/--
16 : 9	
	
MIX	
TEXT	
VOL+	VOL+
VOL-	VOL-
P+	P+
P-	P-
	BACK
TV	TV/DTV
INDEX	INFO
NORM.	EPG
?	FAV
STOP	
RED	RED
GREEN	GREEN
YELLOW	YELLOW

[illegible]