



ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	 / AV
---	-/--
DISPLAY	
SUBPAGE	
TEXT	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SLEEP	SLEEP
DTV	TV/DTV
INDEX	INFO
PC	EPG

ORIGINAL	SUPERIOR
FAV	FAV
ASPECT / SIZE	
HOLD	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO / I/II	SHIFT+MUTE
REVEAL	SHIFT+ 
SUBTITLE	SHIFT+ 
SKIP PREV.	SHIFT+ P-
SKIP NEXT	SHIFT+ P+
TV / RADIO	SHIFT+ TV/DTV
STOP	SHIFT+ 
REW	SHIFT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

