



| ORIGINAL  | SUPERIOR  |
|-----------|-----------|
| STANDBY   | POWER     |
| MUTE      | MUTE      |
| / MENU    | MENU      |
| EXIT      | EXIT      |
| 1/2/3/4/5 | 1/2/3/4/5 |
| 6/7/8/9/0 | 6/7/8/9/0 |
| / SOURCE  | / SOURCE  |
|           | -/--      |
| / DISPLAY |           |
| SIZE      |           |
| SUBOAGE   |           |
| TEXT      |           |
| VOL+      | VOL+      |
| VOL -     | VOL -     |
| CH+       | P+        |
| CH -      | P -       |
| UP        | UP        |
| DOWN      | DOWN      |
| LEFT      | LEFT      |
| RIGHT     | RIGHT     |
| ENTER     | OK        |
|           | BACK      |
| SLEEP     | SLEEP     |
| USB       | TV/DTV    |
| / MOUSE   | INFO      |

| ORIGINAL   | SUPERIOR     |
|------------|--------------|
| INDEX      | EPG          |
| FAV        | FAV          |
| NETFLIX    | / NET TV     |
| HOLD       |              |
| YOUTUBE    | / SMART      |
| RED / A    | RED          |
| GREEN / B  | GREEN        |
| YELLOW / C | YELLOW       |
| BLUE / D   | BLUE         |
| REVEAL     | SHIFT+       |
| P.MODE     | SHIFT+       |
| S.MODE     | SHIFT+       |
| SKIP NEXT  | SHIFT+ P+    |
| SKIP PREV  | SHIFT+ P -   |
| STOP       | SHIFT+       |
| REW        | SHIFT+GREEN  |
| PLAY/PAUSE | SHIFT+YELLOW |
| FWD        | SHIFT+BLUE   |
|            |              |
|            |              |
|            |              |
|            |              |
|            |              |
|            |              |
|            |              |
|            |              |

