



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
≡ / MENU	MENU
↶ / EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT	📺 / SOURCE
-/--	-/--
HOME	🏠
SIZE	📏
MIX	📺
TEXT	📄
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
↶↷	BACK
SLEEP	SLEEP
TV/RADIO	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
EPG/MOUSE	EPG
FAV	FAV
ASPECT	⬆ / NET TV
SUBPAGE	⏸
HOLD	📺 / SMART
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
CANCEL	SHIFT+EXIT
REFRESH	SHIFT+ -/--
REVEAL	SHIFT+ 🏠
SETUP	SHIFT+ 📏
SUB - T	SHIFT+ 📄
SKIP NEXT/PREV	SHIFT+ P+/-
T - SHIFT	SHIFT+SLEEP
INDEX	SHIFT+INFO
P.MODE	SHIFT+EPG
S.MODE	SHIFT+FAV
STOP	SHIFT+ 📺
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY/PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

