



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	AV
DISPL. / OFF	
/ FREEZE	
/ SUBTITLE	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SLEEP	SLEEP
INFO	INFO
GUIDE	EPG
FAV	FAV

ORIGINAL	SUPERIOR
/ ASPECT	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
MEDIA	SHIFT+6
/ LANG.	SHIFT+
SKIP PREV.	SHIFT+ P-
SKIP NEXT	SHIFT+ P+
/ AUDIO	SHIFT+INFO
PRESETS	SHIFT+FAV
PAUSE	SHIFT+
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

