



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
SYSTEM	MENU
CLEAR	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
FUNCTION	/ AV
10+	-/--
OSD	
GOTO	
SETUP	
SUBTITLE	
+	VOL+
-	VOL-
SKIP NEXT	P+
SKIP PREV.	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
SELECT	OK
RETURN	BACK
STEP	SLEEP
L / R	TV/DTV
TITLE	INFO

ORIGINAL	SUPERIOR
DIGEST	EPG
PROGRAM	FAV
OPEN / CLOSE	
PAUSE	
STOP	
REW	GREEN
PLAY	YELLOW
FWD	BLUE
AUDIO	SHIFT+MUTE
RANDOM	SHIFT+ -/--
RESUME	SHIFT+
ZOOM	SHIFT+
ANGLE	SHIFT+
PBC	SHIFT+
REPEAT	SHIFT+BACK
REP A-B	SHIFT+SLEEP
SLOW	SHIFT+TV/DTV

