



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
 / MENU	MENU
 / EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
 / TTX	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
 / RECALL	BACK
 / TV/RADIO	TV/DTV
INFO	INFO
 / EPG	EPG
 / FAV	FAV
RED / FULL	RED
GREEN / V – FORMAT	GREEN
YELLOW / ASPECT	YELLOW
BLUE / TIMER	BLUE

[illegible]