



ORIGINAL	SUPERIOR
POWER	POWER
	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
OPTION	
TEXT	
VOL+	VOL+
VOL -	VOL -
PR+	P+
PR -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
TIMER	SLEEP
	TV/DTV
INFO	INFO
GUIDE	EPG
FAV	FAV
V.F.	/ NET TV
PAUSE	

ORIGINAL	SUPERIOR
RED / MOSAIC	RED
GREEN / SLEEP	GREEN
YELLOW / AUDIO	YELLOW
BLUE / SAT	BLUE
PIP	SHIFT+1
SWAP	SHIFT+2
	SHIFT+6
PAGE UP	SHIFT+UP
PAGE DOWN	SHIFT+DOWN
LAST	SHIFT+BACK
TIME SHIFT	SHIFT+SLEEP
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

