



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV/AV	 / AV
CH / LIST	-/--
DISPLAY	
SIZE	
SUBTITLE	
TV / TXT	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SLEEP	SLEEP
INDEX	INFO
EPG	EPG

ORIGINAL	SUPERIOR
FAV	FAV
HOLD	
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE / SCREEN	BLUE
NICAM / A2	SHIFT+MUTE
CANCEL	SHIFT+EXIT
PICTURE	SHIFT+1
SOUND	SHIFT+2
REC LIST	SHIFT+ -/--
REVEAL	SHIFT+ 
SUBPAGE	SHIFT+DOWN
SKIP PREV.	SHIFT+ P-
SKIP NEXT	SHIFT+ P+
REPEAT	SHIFT+BACK
PAUSE	SHIFT+ 
STOP	SHIFT+ 
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

