



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
--/-	-/--
SHIFT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
	BACK
SLEEP	SLEEP
INFO	INFO
GUIDE	EPG

ORIGINAL	SUPERIOR
FAV	FAV
P. SIZE	/ NET TV
FREEZE	/ SMART
RED	RED
GREEN	GREEN
YELLOW / REPEAT	YELLOW
BLUE / DTV/RADIO	BLUE
I – II	SHIFT+MUTE
P.MODE	SHIFT+1
S.MODE	SHIFT+2
PVR LIST	SHIFT+ -/--
	SHIFT+
SUBTITLE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
FAV -	SHIFT+LEFT
FAV+	SHIFT+RIGHT
	SHIFT+INFO
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

