



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
/ / MENU	MENU
/ / EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
/ / SOURCE	/ SOURCE
/ -/--	-/--
/ TV	
/ / TTX/MIX	
VOL+	VOL+
VOL-	VOL -
/ P+	P+
/ P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
/ ENTER	OK
/ PRE - CH	BACK
/ SLEEP	SLEEP
/ INFO	INFO
RED/TURBO	RED
GREEN/S. MENU	GREEN

ORIGINAL	SUPERIOR
YELLOW/S.MODE	YELLOW
BLUE/P.MODE	BLUE
/ DUAL I - II	SHIFT+MUTE

