



ORIGINAL	SUPERIOR
POWER	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	/ SOURCE
CHN. LIST	-/--
HOME	
SIZE	
MIX	
TEXT	
VOL -/+	VOL -/+
PR -/+	P -/+
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
BACK / RETURN	BACK
SLEEP	SLEEP
AD	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV

ORIGINAL	SUPERIOR
PICTURE	/ NET TV
FREEZE / HOLD	/ SMART VIDEO
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
I/II / NICAM	SHIFT+MUTE
CANCEL	SHIFT+EXIT
SOUND	SHIFT+1
3D	SHIFT+3
PVR LIST	SHIFT+ -/--
REVEAL	SHIFT+
ZOOM	SHIFT+
SUB-PAGE	SHIFT+
SUBTITLE	SHIFT+
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
QUICK	SHIFT+RIGHT
TV / RADIO	SHIFT+ TV/DTV
INDEX	SHIFT+INFO
STOP	SHIFT+
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY / PAUSE	SHIFT+YELLOW
FWD	SHIFT+BLUE

