



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT NEXT	 / SOURCE
DISPLAY	
SUBTITLE	
VOL +	VOL +
VOL -	VOL -
CH +	P +
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
TV VIDEO	TV/DTV
PROGRAM	EPG
EJECT	 / NET TV
PAUSE	
STOP	 / SMART
REW	GREEN

[illegible]