



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	 / SOURCE
-/--	-/--
DISPLAY	
 / FREEZE	
LANGUAGE	
 / TEXT	
VOL+	VOL+
VOL -	VOL -
CH+	P+
CH -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
SLEEP	SLEEP
TV/RADIO	TV/DTV
 / INDEX	INFO

ORIGINAL	SUPERIOR
GUIDE	EPG
FAV	FAV
P.MODE	 / NET TV
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
S.MODE	SHIFT+MUTE
MEDIA	SHIFT+6
 / SIZE	SHIFT+ 
 / SUBTITLE	SHIFT+ 
SKIP NEXT	SHIFT+ P+
SKIP PREV	SHIFT+ P -
PAUSE	SHIFT+ 
STOP	SHIFT+ 
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

