



We are sorry,
PICTURE
NOT
AVAILABLE

ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
TV / AV	 / AV
SHIFT	-/--
	P+
	P -
UP / PR+	UP
DOWN / PR -	DOWN
LEFT / VOL -	LEFT
RIGHT / VOL+	RIGHT
OK / LIST	OK
 PR	BACK
SLEEP	SLEEP
TV / RADIO	TV/DTV
INFO	INFO
EPG	EPG
FAV	FAV
RED / FIND	RED
GREEN / V – FORMAT	GREEN
YELLOW / TXT	YELLOW
BLUE / 	BLUE

[illegible]