



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV	 / SOURCE
P100	-/--
	
SWP	
MIX	
TV / TXT	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UPDATE	UP
SUB	DOWN
OK	OK
REV	BACK
TV	TV/DTV
PURPLE	INFO
PP	EPG
	FAV
DOUB.	 / NET TV
HOLD	 / SMART

[illegible]