



ORIGINAL	SUPERIOR
	POWER
	MUTE
MENU	MENU
STEREO ON/OFF	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV	/ SOURCE
-/--	-/--
REVEAL	
DOUBLE	
MIX	
TX	
+	VOL+
-	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
	OK
SEL	BACK
TIMER	SLEEP
TV	TV/DTV
INFO	INFO

ORIGINAL	SUPERIOR
STORE	EPG
UPDATE	FAV
HOLD	/ SMART
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
CLOCK / USB	SHIFT+POWER
SYST	SHIFT+MENU
PS <=>	SHIFT+
MONO A - B	SHIFT+
P 100	SHIFT+

