



ORIGINAL	SUPERIOR
POWER	POWER
MUTE	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
SOURCE	 / SOURCE
GO TO	-/--
TIME SHIFT	
ZOOM	
SUBTITLE	
TEXT	
VOL+	VOL+
VOL -	VOL -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
BACK	BACK
TIMER	SLEEP
TV SYSTEM	TV/DTV
INFO	INFO
GUIDE	EPG
HOME	FAV
RED	RED

ORIGINAL	SUPERIOR
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
AUDIO	SHIFT+MUTE
COPY	SHIFT+1
MUSIC	SHIFT+2
REC. LIST	SHIFT+ -/--
SETUP	SHIFT+ 
SLOW	SHIFT+LEFT
SKIP NEXT	SHIFT+ P-
SKIP PREV	SHIFT+ P+
REPEAT	SHIFT+BACK
REPEAT A – B	SHIFT+SLEEP
PAUSE	SHIFT+ 
STOP	SHIFT+ 
REC	SHIFT+RED
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

