



ORIGINAL	SUPERIOR
STANDBY	POWER
MUTE	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
DVB / DVD	 / SOURCE
+10	-/--
Q-PLAY	
ZOOM	
ANGLE	
TELETEXT	
VOL+	VOL+
VOL-	VOL-
CH+	P+
CH-	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
OK	OK
RETURN	BACK
TV / RADIO	TV/DTV
SCAN MODE	INFO
EPG	EPG
GO TO	FAV

ORIGINAL	SUPERIOR
RED / F1	RED
GREEN / F2	GREEN
YELLOW / F3	YELLOW
BLUE / F4	BLUE
AUDIO	SHIFT+MUTE
SETUP	SHIFT+ 
SUBTITLE	SHIFT+ 
SKIP NEXT / PAGE+	SHIFT+ P+
SKIP PREV / PAGE -	SHIFT+ P -
 / RECALL	SHIFT+LEFT
REPEAT	SHIFT+BACK
A - B	SHIFT+SLEEP
EJECT	SHIFT+ 
PAUSE	SHIFT+ 
STOP	SHIFT+ 
REW	SHIFT+GREEN
PLAY	SHIFT+YELLOW
FWD	SHIFT+BLUE

