



ORIGINAL	SUPERIOR
	POWER
MUTE	MUTE
MENU	MENU
EXIT	EXIT
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
AV	/ SOURCE
+100	-/--
DISPLAY	
SCART 1 / 2	
TELETEXT	
VOL+	VOL+
VOL -	VOL -
P+	P+
P -	P -
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
	OK
RTN	BACK
SLEEP	SLEEP
TV	TV/DTV
	INFO

ORIGINAL	SUPERIOR
SV	EPG
PC	FAV
AUTO	/ NET TV
QUICK	
FREEZE	/ SMART
RED	RED
GREEN	GREEN
YELLOW	YELLOW
BLUE	BLUE
SOUND	SHIFT+MUTE
	SHIFT+EXIT
PIP INPUT	SHIFT+
PIP SWAP	SHIFT+ -/--
	SHIFT+
	SHIFT+
SCALING	SHIFT+
ZOOM+	SHIFT+UP
ZOOM -	SHIFT+DOWN
	SHIFT+SLEEP

